


ML


INSTALLATION // INSTALLATIE // INSTALACIÓN // INSTALAÇÃO  
INSTALLAZIONE // MONTAŽ // INŠTALACIJA

## Kit relève / Boiler connection kit (074993 - UTW-KBSXS)







1




2




3




4






5




6







9



10




## ► Backup, 1 heating circuit




- 9 - Pressure sensor (Value)
- 10 - Valve
- 11 - Drain valve
- 12 - Circulation pump
- 14 - Safety valve
- 15 - Heat exchanger (Condensor)
- 30 - Outdoor unit
- 31 - Hydraulic unit (heating only)
- 50 - Expansion vessel
- 53 - Directional valve
- 54 - Manometer
- 56 - Non return valve
- 57 - Decoupling bottle
- 60 - Heat pump electrical backup
- 61 - DHW electrical backup
- 100 - Radiator
- 101 - Underfloor heating system
- 102 - Dynamic radiator (fan-convector)
- 105 - Room thermostat or room sensor (zone 1)
- 110 - Outdoor sensor
- 150 - Shut-off
- 151 - Safety valve
- 152 - Thermostatic mixer valve
- 210 - Buffer tank
- 230 - Boiler relief
- 231 - Boiler thermostat
- 520 - Return temp. sensor (heating circuit)
- 521 - Flow temp. sensor (heating circuit)

► Back-up, 2 heating circuits and mixed domestic hot water tank




- 9 - Pressure sensor (Value)
- 10 - Valve
- 11 - Drain valve
- 12 - Circulation pump
- 14 - Safety valve
- 15 - Heat exchanger (Condensor)
- 30 - Outdoor unit
- 31 - Hydraulic unit (heating only)
- 50 - Expansion vessel
- 53 - Directional valve
- 54 - Manometer
- 56 - Non return valve
- 57 - Decoupling bottle
- 60 - Heat pump electrical backup
- 61 - DHW electrical backup
- 100 - Radiator
- 101 - Underfloor heating system
- 102 - Dynamic radiator (fan-convector)
- 105 - Room thermostat or room sensor (zone 1)
- 110 - Outdoor sensor
- 150 - Shut-off
- 151 - Safety valve
- 152 - Thermostatic mixer valve
- 210 - Buffer tank
- 230 - Boiler relief
- 231 - Boiler thermostat
- 250 - 2 circuit kit
- 252 - Mixing valve
- 520 - Return temp. sensor (heating circuit)
- 521 - Flow temp. sensor (heating circuit)
- 530 - DHW temp. sensor
- 531 - DHW electrical backup thermal safety
- 540 - Flow temp. sensor (Mixed heating circuit)


11




12




13




14






Nr	Code	Qty
1	142716	2
2	110392	1
3	182992	1
4	104750	1
5	142735	4
6	157306	1
7	142442	1
8	188404	1
9	110898	1
10	122640	1
11	198746	1
12	149001	3
13	174207	1
20	133356	1



20







Points de collecte sur [www.quefairedemesdechets.fr](http://www.quefairedemesdechets.fr)

*Commissioning date:*

*Address of your heating installer or customer service.*

**AMBB - SATC**  
Rue des fondeurs 59660 MERVILLE  
FRANCE